

**Temium**

**BLUETOOTH SELFIE STICK**  
INSTRUCTION MANUAL



MODEL 4153006

**What's in the Box**

- Selfie stick with built-in battery and Bluetooth shutter
- USB charging cable



**Fitting Your Phone**

1. Tilt the phone clip.



2. Pull to open the bracket of the phone clip and place your phone in the bracket. Gently release the bracket so your phone is snug and secure.



Fits all phones width between 3.5-5.5 inches

3. Extend the monopod to the desired length.



Extendable length from 20 cm to 78 cm

**Pairing Selfie Stick to Your Phone**

1. Turn on the Bluetooth function of your phone.
2. Turn on the selfie stick by pressing the shutter button for about 3 seconds until the blue light on the shutter button illuminates.
  - The blue light will flash indicating the selfie stick is in pairing mode.
3. Go to your phone's Bluetooth device list.
4. Select "BT150" to connect your phone to the selfie stick.
  - The blue light will go out.



**Taking Photos with Selfie Stick**


1. Open the camera function on your phone.
  2. Press the shutter button on the selfie stick to take photos.
- To turn off the selfie stick, press and hold the shutter button for about 3 seconds.



**Charging Selfie Stick**

1. Connect the Micro-USB end of the supplied USB cable to the charging port on the bottom of the selfie stick.
2. Connect the other end of the USB cable to your computer.
  - The red charging light will illuminate when charging.
3. When the unit is fully charged, the red charging light will go out.

Charging light



USB charging port

**Specifications**

Charging input:	0.5A
Charging voltage:	5V
Charging time:	0.5 hour
Standby time:	72 hours

**DISPOSAL**

As a responsible retailer we care about the environment.



As such we urge you to follow the correct disposal procedure for the appliance and packaging materials. This will help conserve natural resources and ensure that it is recycled in a manner that protects health and the environment.

You must dispose of this appliance and its packaging according to local laws and regulations.

Because this appliance contains electronic components, the appliance and its accessories must be disposed of separately from household waste when the appliance reaches its end of life.

Contact your local authority to learn about disposal and recycling.

The appliance should be taken to your local collection point for recycling. Some collection points accept appliance free of charge.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.