



	A	B	C	D	E	F	G	H
50Q8*B 50QB8*	43.9 inches (1114.2 mm) (111.42 cm)	25.4 inches (644.6 mm) (64.46 cm)	2.1 inches (53.9 mm) (5.39 cm)	28.5 inches (723.0 mm) (72.30 cm)	9.4 inches (239.8 mm) (23.98 cm)	49.5 inches (125 cm)	30.2 lbs (13.7 kg)	39.9 lbs (18.1 kg)

*: 0-9, A-Z




	VESA A x B (mm)	C (mm)	D x 4
50Q8*B 50QB8*	200 x 200	26-28	M8


*: 0-9, A-Z

SAMSUNG

QUICK SETUP GUIDE
GUIDE D'INSTALLATION RAPIDE
GUÍA RÁPIDA DE CONFIGURACIÓN
GUIA RÁPIDO DE INSTALAÇÃO
KURZANLEITUNG ZUR KONFIGURATION
GUIDA DI INSTALLAZIONE RAPIDA




BN68-13689A-00







	USB		USB ←→
	OPTICAL		↔
	ARC		HDMI (eARC)
			HDMI
			LAN
			ANT




1




2




3




4




5



6



7



8

